



1. Add Krystol Internal Membrane (KIM) to the concrete mix in the base slab and walls to ensure water is contained and not contaminated from outside sources. Refer to Application Instructions 1.11 to 1.15 — Use of KIM Admixture.
2. Use the Krystol Waterstop System (Internal) to waterproof horizontal construction joints where the wall sits on the slab. Refer to Application Instruction 4.11 — Waterproofing Horizontal Construction Joints (Internal Method).
3. Use the Krystol Waterstop System (External) to waterproof construction joints in the slab. Refer to Application Instruction 4.12 — Waterproofing Horizontal & Vertical Construction Joints (External Method).
4. Use Krystol Waterstop Grout to waterproof form tie holes. Refer to Application Instruction 4.17 — Waterproofing Tie Holes & Pipe Penetrations.
5. Use Krystol Waterstop Grout to waterproof pipe penetrations. Refer to Application Instruction 4.17 — Waterproofing Tie Holes & Pipe Penetrations.
6. Use the Krystol Waterstop System (External) to waterproof vertical construction joints in the walls. Refer to Application Instruction 4.12 — Waterproofing Horizontal & Vertical Construction Joints (External Method).