



1. Add Krystol Internal Membrane (KIM) to the concrete mix to ensure water is contained and not contaminated from outside sources. Refer to Application Instruction 1.11 to 1.15 — Use of KIM Admixture.
2. Use the Krystol Waterstop System (Internal) to waterproof horizontal construction joints where a wall meets a slab. Refer to Application Instruction 4.11 — Waterproofing Horizontal Construction Joints (Internal Method).
3. Use the Krystol Waterstop System (External) to waterproof construction joints in the slabs. Refer to Application Instruction 4.12 — Waterproofing Horizontal & Vertical Construction Joints (External Method).
4. Use Krystol Waterstop Grout to waterproof form tie holes. Refer to Application Instruction 4.14 — Waterproofing Tie Holes & Pipe Penetrations.
5. Use Krystol Waterstop Grout to waterproof pipe penetrations. Refer to Application Instruction 5.33 — Waterproofing Tie Holes and Pipe Penetrations.
6. Use the Krystol Waterstop System (External) to waterproof vertical construction joints in the walls. Refer to Application Instruction 4.12 — Waterproofing Horizontal & Vertical Construction Joints (External Method).